



TRUCK PARTS >

TRAILER PARTS >

NEW PARTS >

OVER 30,000 PARTS AVAILABLE ONLINE NOW FROM universal COMPONENTS

LATEST NEW PARTS

Contact sales now for further details: T - 0114 261 1122

MRSA0022

Shock Absorber Front O/O
• To Suit: Mercedes Atego

- Open Length 665mm
- Closed Length 405mm
- Bush A 16 x 50mm
- Bush B 16 x 50mm



OEM: 9723230100

MRSA0023

Shock Absorber Rear O/O
• To Suit: Mercedes Atego

- Open Length 827mm
- Closed Length 556mm
- Bush A 16 x 62mm
- Bush B 20 x 50mm



OEM: 9723260200

RNSA0018

Shock Absorber Front O/O
• To Suit: Renault Premium DXI

- Open Length 658mm
- Closed Length 409mm
- Bush A 20 x 50mm
- Bush B 20 x 50mm



OEM: 7420867988

VLSA0007

Shock Absorber Rear O/O
• To Suit: Volvo FL

- Open Length 720mm
- Closed Length 435mm
- Bush A 20 x 50mm
- Bush B 20 x 50mm



OEM: 20386245

Pat Hickey Truck & Trailer Spares

Castlemungret Industrial Estate,
Mungret, Co. Limerick V94 H288
P: 061-303900
www.pathickey.com

SC0099

Clearpass Spray Flap

- To Suit: Scania
- 710mm x 300mm



OEM: 1368621

Manufacturer's and other wholesaler's part numbers used in this publication are for cross reference purposes only and do not imply anything about the origin or manufacturer of the product

VISIT US ONLINE AT WWW.UCGROUP.COM

SEP-19-16